Installation


Boxspring bracket


Video

You can watch the installation videos here.

www.airzag.eu/installation

Required material:





Place holding plates on your table and place placeholders under them.



Adjust the angle so that it points upwards.



Place the bracket on the holding plates (make sure that the holes are centered).




Position AIRZAG on bracket.




Fold down the upper half of the AIRZAG.



Put on the outer screws (do not tighten). Repeat on the opposite side.




Pull up AIRZAG.



Screw in the remaining screws and tighten all screws (do not overtighten).
Repeat on the opposite side.



Place the cross connector with the markings on the topside on the table.



Apply double adhesive on the left and right (remove protective film from double adhesive).



Position AIRZAG with bracket on the cross connector and press firmly (pay attention to markings).



Close AIRZAG again and slide it between the bed and the mattress.



Gebrauchsanleitung

Boxspring bracket


Dear Customer,

With your purchase of a boxspring bracket, you have chosen an innovative product from 4INVEN-TIONS. We have used only high quality and recyclable materials for this product and guarantee you the best quality.


With kind regards, 4INVENTIONS GmbH

Areas of use:

The Boxspring bracket is suitable for beds where the mattress is at the same height as the bed edge or where there is no bed edge (e.g. box spring beds). It is only used to mount the "AIRZAG" duvet aerator on a bed frame. No permanent connection to the bed frame is necessary. The weight of the mattress is sufficient to hold the bracket in place.



Package contents



Important information



Do not use any aggressive cleaning products. Wipe off only with a damp cloth and a little soap. Avoid strong rubbing, as it might damage the polished surfaces.



Not a toy! Not suitable for children under 6 years of age.

Do not use the Boxspring bracket outside of the intended area of use (see areas of use).

Do not over-tighten screws. Tighten them with care! Screwdriver not included!
Please use a Phillips screwdriver size PH1.

You can find further information at **www.airzag.eu**

Warranty

The warranty provided by the manufacturer only applies in the event of original defects that are due to faults on the manufacturer's part. Warranty claims do not apply for damage resulting from improper use of the Slide-in bracket, nor is the manufacturer liable for such use. Examples of such cases would be: destruction of the Slide-in bracket by overloading, incorrect cleaning or personal injury caused by incorrect use.

Please read the entire instruction manual carefully.

Further information and support

Quality & Design by Tecnoservice LH GmbH Dr.J.Köllenspergerstraße 8 39011 Lana / Italy www.4inventions.eu Made in Italy by Tecnoservice LH GmbH

Mail: support@4inventions.eu **Tel.** 0039 0473 86 06 08

AIRZAG® is Patented and all Trademarks are owned by Tecnoservice LH GmbH and Associates. All Rights reserved.

Installation videos and FAQ's at: www.airzag.eu

