

# AIRZAG® Duvet Aerator

## Instructions

Dear Customer,  
With your purchase of an AIRZAG duvet aerator, you have chosen an innovative product from 4INVENTIONS. We have used only high quality and recyclable materials for this product and guarantee you the best quality.

AIR - stands for air, and ZAG describes a simple and quick gesture. Hygienic airing of your bed really couldn't be faster or easier: Lift up AIRZAG, lay the duvet over it and open a window.


Daily airing is important for health and well-being. With the AIRZAG duvet aerator, the duvet and mattress is optimally aired out from all exposed sides. Airing out the bedroom enhances the effect.

With kind regards,  
4INVENTIONS GmbH

### Dimensions

AIRZAG set up.

AIRZAG closed.



### Important information

**Warning: Danger of crushing and pinching!**  
When folding up the AIRZAG, make absolutely sure to keep fingers and other body parts away from the shear zone of the components.

**4 KG**  
Maximum load with even distribution of the weight: **4 kg**. The AIRZAG is suitable for use with one single duvet (approx. 3 - 4 kg). **Absolutely avoid overloading!**

**Do not use any aggressive cleaning products.**  
Wipe off only with a damp cloth and a little soap. Avoid strong rubbing, as it might damage the polished surfaces.

**Do not heat**, risk of fire at temperatures over 300°C

**Not a toy!** Not suitable for children under 6 years of age.

A flexible, elastic movement of the AIRZAG is intended and does not represent any kind of quality defect. When using, always pay attention to the **vertical position** of the AIRZAG!

Do not use the AIRZAG beyond its intended scope of use. The AIRZAG is intended for airing a duvet (**up to a maximum of 4 kg**). Avoid loads lasting more than 1 day.

Do not over-tighten screws. Tighten them with care!

If the AIRZAG should be removed from the edge of the bed at a later point in time, the screw holes that were made during installation can be sealed again with a wax crayon in the corresponding colour.

**There are three installation options for the AIRZAG. Please choose one of the options.**











You can find further information at [www.airzag.eu](http://www.airzag.eu)

### Warranty

The warranty provided by the manufacturer only applies in the event of original defects that are due to faults on the manufacturer's part. Warranty claims do not apply for damage resulting from improper use of the AIRZAG, nor is the manufacturer liable for such use. Examples of such cases would be: destruction of the AIRZAG by overloading, incorrect cleaning or personal injury caused by incorrect use.

**Please read the entire instruction manual carefully**

### Package contents

- 1 x AIRZAG 
- 6 x M3x8 metric screw 
- 2 x M3x45 metric screw 
- 10 x wood screw, countersunk head Ø3x16 
- 2 x wood screw, flat head Ø3x50 
- Silicone tube installation aid 
- 2 x steel bracket 
- 2 x threaded plate for bracket 
- 2 x double-sided adhesive tape 
- 1 x instruction manual 

### Further information and support

Quality & Design by Tecnoservice LH GmbH  
Dr.J.Koellenspergerstrasse 8  
39011 Lana / Italy  
[www.4inventions.eu](http://www.4inventions.eu)  
Made in Italy by Tecnoservice LH GmbH

**Mail:** [support@4inventions.eu](mailto:support@4inventions.eu)  
**Quick-Chat:** [www.airzag.eu](http://www.airzag.eu) (8.30 a.m. - 4.30 p.m. Mon-Fri. UTC +1)  
**Tel.** 0039 0473 86 06 08  
AIRZAG® is Patented and all Trademarks are owned by Tecnoservice LH GmbH and Associates. All Rights reserved.


Installation videos and FAQ's at [www.airzag.eu](http://www.airzag.eu)




### Info

#### Installation assistance

Screwdriver not included!  
Please use a Phillips screwdriver size PH1.



Attach installation tube to the screwdriver.



Thread screw on the end of the tube. The installation tube holds the screw in place on the screwdriver and thereby facilitates attaching the screw.

#### Before installation

Installation variant A only works with an edge of a bed with a minimum width of 3 cm and with solid wood (no chip board with veneer). Alternatively, choose version B or C for a minimum width of 2 cm.

 With veneered wood, pre-drill a 1.5 mm hole.

### Double bed



Two AIRZAG are required for a double bed.  
**Please note:** When installing on a double bed, maintain a minimum distance of 5 cm between the two AIRZAG! Only in this way can the duvet aerator be used correctly.

## Directions for use



**1**  
Pull up AIRZAG until it snaps in place.



**2**  
Place duvet over it.



**3**  
Straighten out duvet evenly and make sure that the AIRZAG is standing straight.



**4**  
After airing: Remove duvet. Briefly pull AIRZAG slightly upwards, press rods inward.



**5**  
Lower and close AIRZAG.

# Installation variants

**i** Please select one of the three installation options.


## A 8 min Directly on the edge of the bed without bracket

2x 

6x 




1 Position and align AIRZAG, partially open and fold down.



2 Attach the two outside screws at both ends.



3 Pull up AIRZAG and set it up completely.



4 Attach the inner screws, two each per side.


## B 12 min On the edge of the bed with bracket and screw connection from the inside

2x  6x  10x 

2x  2x 



1 Open AIRZAG completely until it snaps in place and then lay it down.



2 Attach both brackets with thread plate on the AIRZAG using 4 screws each.






3 Close AIRZAG, position and align.



4 Screw in screws on the back side of both brackets into the bed frame.


## C 18 min On the face of the edge of the bed using bracket

2x  6x  10x 


2x  2x  2x 




1 Open AIRZAG completely until it snaps in place and then lay it down.




2 Temporarily screw on both brackets on the AIRZAG with thread plate and 2 screws positioned diagonally on the thread plate.




3 Close AIRZAG and attach adhesive tape on both brackets. Remove protective foil.




4 Position AIRZAG horizontally and press firmly.




5 Open AIRZAG and screw on with two screws each.



6 Undo screws from step 2. Disassemble AIRZAG.



7 Secure both brackets with remaining screws.



8 Mount AIRZAG again. Fasten with four screws each.